



Equipped with  
**Answer Back**

Whether it's the pace of your day or trends you create, here's a ride that keeps up with you.

No matter where you go, you'll never lose track of your RayZR SR. With its convenient new **Answer Back function**, you can find your ride instantly. Just tap the Answer Back button on the app and look for the flashing blinkers and sound of the buzzer. It's that easy!



**NEW**  
**LED DRL**

In sporty new **Ice-fluo Vermillion**, **Cyber Green** and **Matte Black** drip and flexing a new **LED DRL**, the Street Rally is levelling up and how!



## SPECIFICATIONS

### ENGINE

Engine Type	Air Cooled, 4-Stroke, SOHC, 2-Valve
Hybrid	Equipped
Displacement	125cc
Bore & Stroke	52.4 x 57.9mm
Compression Ratio	10.2:1
Maximum Horse Power	6.0kW(8.2PS)/6500r/min
Maximum Torque	10.3N.m(1.0kgf.m)/5000r/min
(With Assist Function Working)	
Stop & Start System	Equipped
Smart Motor Generator (SMG) System	Equipped
Fuel System	Fuel Injection
Starting System Type	Electric Starter and Kick Starter
Transmission Type	V-Belt Automatic

### CHASSIS

Suspension Type (Front/Rear)	Telescopic Fork / Unit Swing
Tyre Size (Front)	90/90-12 Tubeless
Tyre Size (Rear)	110/90-10 Tubeless
UBS	Equipped
Brake Type (Front)	SR & Disc: 190mm
	Drum: 130mm
Brake Type (Rear)	Drum

### ELECTRICAL

Battery	Maintenance Free - 12V, 5.0 Ah
Ignition System	TCI (Transistor Controlled Ignition)
Headlight (Class C)	SR & RayZR Disc: LED
	Drum: Halogen 12V, 35/35Wx1
	12V, 21/5Wx1
Brake Light/Tail Light	Equipped
DRL/Position Light	Equipped
Side Stand Engine Cut-off Switch	Equipped
Meter Console	SR & RayZR Disc: Digital
	Drum: Analogue
Bluetooth (Y-Connect)	SR & RayZR Disc: Equipped
Answer Back	SR Equipped

### DIMENSIONS

Overall Length x Width x Height	SR: 1880 mm x 750 mm x 1190 mm
	RayZR: 1880 mm x 685 mm x 1190 mm
Seat Height	785mm
Wheelbase	1280mm
Minimum Ground Clearance	145mm
Fuel Tank Capacity	5.2L
Under-Seat Storage	21L
Weight	99kg
(With Oil & Full Fuel Tank)	

## HYBRID

### COLOUR VARIANTS



The specifications and designs of the motorcycles shown here may vary according to the requirements and are subject to change without prior notice. Colours shown may not match the actual colour due to printing limitations. \*Conditions apply. \*\*Warranty extended for engine, FI system, AIS system and Electricals including wiring harness, whichever is earlier. 5-Year warranty\* only applicable in case of purchase of Yamaha Protection Plus Policy during validity period. Please refer to Yamaha Protection Plus Policy for more details.



Authorised Dealer



**KEEP RAYZING**  
**CYGNUS RAYZR 125 Fi HYBRID**

The call of the BLUE



**STREET RALLY**




Equipped with  
**Answer Back**

\*Available on select models

# HYBRID

## KEEP RAYZING WITH HYBRID POWER




### 125CC FI ENGINE WITH HYBRID POWER ASSIST

The RayZR and RayZR Street Rally engine packs a powerful punch. It cranks out optimum power for a thrilling ride with incredible mileage and eco-friendliness.

### AUTOMATIC STOP & START SYSTEM

The Stop & Start system automatically stops the engine when the vehicle is at a stop and idling, helping you save fuel. With a simple twist of the throttle, you can easily re-start the engine and get underway again.




### SMART MOTOR GENERATOR

It enables you to turn on the engine quietly and easily, whenever you are ready to go.

### HYBRID POWER ASSIST

While on the go, the SMG charges the onboard battery. The SMG along with the engine produces 8.2 PS power and up to 10.3 Nm torque for quicker acceleration when starting from a stop.



### NEW GRAPHICS

### NEW LED DRL

